

A

B

C


D

E


F

G

D TACT SWITCH (1) P.C.B. (REPX0236A)



E TACT SWITCH (2) P.C.B. (REPX0236A)



F HEAD PHONE P.C.B. (REPX0236A)

