

Model: HCD-S300, DAV-S300

No. 687R1

Subject: New and old board compatibility (Power & Audio)

Date: December 10, 2001

Symptom:
(1111)

The Power and Audio boards were changed halfway through manufacturing. Please refer to the following procedures for compatibility.


Solution:

BOARD COMBINATION					
	DESCRIPTION	PART NUMBER	DESCRIPTION	PART NUMBER	HOW TO HANDLE
1	OLD POWER	1-676-632-11	OLD AUDIO	1-676-635-11	REFER TO HIFI SB #651R1
2	NEW POWER	1-680-863-21	OLD AUDIO	1-676-635-11	ADD NEW T/N BOARD (A-4727-807-A)
3	OLD POWER	1-676-632-11	NEW AUDIO	1-680-861-12	ADD LEAD WIRE (A-4735-718-A)

Procedure

Combination of old POWER Board (1-676-632-11) and old AUDIO Board (1-676-635-11). Refer to Service Bulletin HiFi #651R1.

Combination of new POWER Board and old Audio Board. 1. Mount the new T/N board to the POWER Board using one screw of the POWER Board. If old T/N board is mounted to POWER Board, remove it. 2. Plug the lead wire from the POWER Board to the connector of the T/N Board. 3. Secure the lead wire using the lead pin.



Combination of Old POWER Board (1-676-632-11) and new AUDIO Board (1-680-861-12) 1. Cut pattern of old POWER Board (See HiFi Bulletin 651R1 for details). 2. Route lead wire (A-4735-718-A) as below. 3. Fix lead wire with glue (SC-608LV: 7-432-912-48), tape (7-632-661-00) as described below. Plug lead wire into the connector of the T/N board.

