



WIRING  
 EACH OPENING OR APPLIANCE  
 SHOULD BE WIRED INDIVIDUALLY  
 BACK TO PANEL  
WINDOWS IN SERIES  
 MORE THAN ONE WINDOW OR DOOR  
 MAY BE WIRED TO A SPECIFIC  
 ZONE (IN SERIES IN THE PANEL)  
 (E. ZONE 5 IN THIS LAYOUT)  
SMOKE DETECTORS  
 INSTALL TO ZONE 6  
 2 WIRES TO Z6 AND COM  
 2 WIRES TO AUX + -  
 INSTALL A RESISTOR ACCESS RELAY  
MOTION DETECTORS  
 USE SEPERATE ZONES  
 FOR EACH MOTION DETECTOR  
UNUSED ZONES  
 LOOP OFF ANY UNUSED ZONES (E.  
 ZONE 2 IN THIS LAYOUT).