



NOTE:  
USE LUGS PT\*475-15656 FOR  
WIRING SW. LEADS TO RECEIVER  
& TRANSMITTER.

SCHEMATIC

