



Out of Tune

In "Build a Versatile Nickel-Cadmium Battery Charger" (October 1974), the schematic should be modified as follows: The bottom of the secondary of *T1* should be connected to the *B1-BP1*-negative node, rather than *R1-S2A*.

DECEMBER 1974