

Pioneer

Service Manual

ORDER NO.
RRV2225

DVD PLAYER

DV-525

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	Region No.	Remarks
	DV-525			
WVXJ	○	AC220-240V	2	
WYXJ/SP	○	AC220-240V	2	

● **This service manual should be used together with the following manual(s):**

Model No.	Order No.	Remarks
DV-525/WV	RRV2158	

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES : ● Parts marked by “ NSP ” are generally unavailable because they are not in our Master Spare Parts List.

● The  mark found on some component parts indicates the importance of the safety factor of the part.


Therefore, when replacing, be sure to use parts of identical designation.

● Screw adjacent to ▼ mark on the product are used for disassembly.

● Reference Nos. indicate the pages and Nos. in the service manual for the base model.

■ CONTRAST TABLE for WVXJ TYPE

DV-525/WVXJ and WV are constructed the same except for the following:

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			WV type	WVXJ type	
P5 - 1		PACKING			
P5 - 2		Audio Cord	VDE1033	VDE1052	
P5 - 7		Video Cord	VDE1034	VDE1053	
P5 - 18		Packing Case	VHG1839	VHG1881	
		Power Cord	ADG7004	ADG1156	
		EXTERIOR SECTION			
P6 - 6		Tray	VNL1731	VNK4570	
		FRONT PANEL SECTION			
P7 - 3		Flexible Cable (14P)	VDA1724	VDA1744	
P7 - 4		Flexible Cable (09P)	VDA1725	VDA1746	
		BOTTOM VIEW SECTION			
P9 - 9		Flexible Cable (12P)	VDA1692	VDA1749	
P9 -10		Flexible Cable (26P)	VDA1689	VDA1742	
P9 -11		Flexible Cable (33P)	VDA1723	VDA1743	
P9 -12		Flexible Cable (07P)	VDA1729	VDA1745	
P9 -13		Flexible Cable (12P)	VDA1730	VDA1747	
P9 -17		Rear Panel	VNA2087	VNA2074	
		LOADING MECHANISM ASSY			
P10 - 6		Loading Base	VNL1844	VNL1854	
P10 -15		Connector Assy	VKP2198	VKP2218	
P10 -21		Flexible Cable (24P)	VDA1701	VDA1748	
P10 -22		Cushion	VEB1312	Not used	

■ CONTRAST TABLE for WYXJ/SP TYPE

DV-525/WYXJ/SP and WY/SP are constructed the same except for the following:

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			WY/SP type	WYXJ/SP type	
P5 - 1	⚠	PACKING Audio Cord	VDE1033	VDE1052	
P5 - 2		Video Cord	VDE1034	VDE1053	
P5 - 7		Packing Case	VHG1830	VHG1882	
P5 -18		Power Cord	ADG1127	ADG1154	
P6 - 6		EXTERIOR SECTION Tray	VNL1731	VNK4570	
P7 - 3		FRONT PANEL SECTION Flexible Cable (14P)	VDA1724	VDA1744	
P7 - 4		Flexible Cable (09P)	VDA1725	VDA1746	
P9 - 9		BOTTOM VIEW SECTION Flexible Cable (12P)	VDA1692	VDA1749	
P9 -10		Flexible Cable (26P)	VDA1689	VDA1742	
P9 -11		Flexible Cable (33P)	VDA1723	VDA1743	
P9 -14		Flexible Cable (08P)	VDA1731	VDA1803	
P9 -17		Rear Panel	VNA2109	VNA2158	
P10 - 6		LOADING MECHANISM ASSY Loading Base	VNL1844	VNL1854	
P10 -15		Connector Assy	VKP2198	VKP2218	
P10 -21		Flexible Cable (24P)	VDA1701	VDA1748	
P10 -22		Cushion	VEB1312	Not used	