



NOTES:

1. CUT FOR USE WITH 438-249 CASSETTE REMOTE CONTROL KIT. CONNECT LABELED POINTS ON 10A155 TO SIMILIARLY LABELED POINTS ON 438-249.

- DENOTES PINS ON P.C.BOARD
- △ " LUGS ON ANTENNA COIL
- " HOLES IN P.C.BOARD

- UNLESS OTHERWISE SPECIFIED:
2. ALL FIXED RESISTORS ARE 1/2 WATT
  3. TOLERANCES ON ALL FIXED RESISTORS ±10%
  4. RESISTANCE VALUES IN OHMS.  
K=1000 OHMS.
  5. CAPACITANCE VALUES IN MICROFARADS.
  6. TERMINAL NUMBERING FOR SWITCH "S1" IS FOR REFERENCE ONLY. SWITCH IS SHOWN VIEWED FROM KNOB END WITH ROTOR IN EXTREME C.C.W. POSITION.
  7. "CW" DENOTES DIRECTION OF ROTATION AS VIEWED FROM KNOB OR ACTUATOR END AS INDICATED FOR R9.
  8. VOLTAGES MEASURED WITH 20,000Ω/V VOM; MAY VARY ±10%.
  9. \* VOLTAGE INDICATED ON VOM IS MEANINGLESS.



