

Manual Cross Reference

Many manufacturers stick 2, 3 even more models in one manual...and then never give you any idea where to find them.

JVC VCR X-REFERENCE

Model #	Use Manual
HR-S10U	HR-S100U
HR-DX24U	HR-DX22U
HR-DX25U	HR-DX20U
HR-DX42U	HR-DX22U
HR-DX44U	HR-DX22U
HR-VP54U	HR-J410U
HR-DX64U	HR-DX62U
HR-VP66U	HR-VP65U
HR-VP81U	HR-VP628U
HR-J220U	HR-A21U
HR-D310	HR-D400U
HR-D320	HR-D400U
HR-D400	HR-D400U
HR-D410	HR-D750U
HR-VP412U	HR-J410U
HR-VP416U	HR-J410U
HR-J420U	HR-A41U
HR-VP422U	HR-VP55U
HR-J430U	HR-A42U
HR-VP436U	HR-VP434U
HR-D440	HR-D400U
HR-J440U	HR-A43U
HR-J443U	HR-A43U
HR-D550U	HR-D540U
HR-D566U	HR-D565U
HR-VP604U	HR-J600U
HR-VP606U	HR-J600U
HR-VP612U	HR-J610U
HR-J622U	HR-A61U
HR-J630U	HR-A62U
HR-J633U	HR-A62U
HR-VP636U	HR-VP634U
HR-J640U	HR-A63U
HR-J643U	HR-A63U
HR-VP644U	HR-J642U

HR-VP646U	HR-J642U
HR-VP648U	HR-J642U
HR-VP720U	HR-VP628U
HR-D740U	HR-D730U
HR-D750	HR-D750U
HR-D920U	HR-D910U
HR-D930U	HR-D910U
HR-D970U	HR-D960U
HR-J2002U	HR-A21U
HR-J4404UM	HR-J4004UM
HR-S6900U	HR-S4900U
HR-J7004UM	HR-J6004UM
HR-S7200U	HR-S5200U

Above last edited 07-08-97

Panasonic/Quasar VCR Manual X-REF

Model #	Use Manual
PV-A850	PV-8000
PV-1222	PV-1230
PV-1225	PV-1230
PV-M1325W	PV-M1325
PV-M1337	PV-M1327
PV-1342	PV-1340
PV-M1345	PV-M1325
PV-M1346	PV-M1326
PV-M1347	PV-M1327
PV-M1355W	PV-M1325
PV-M1356	PV-M1326
PV-M1357W	PV-M1327
PV-1361	PV-1360
PV-1362	PV-1360
PV-1362-K	PV-1360
PV-M1365AD	PV-M1325
PV-1366	PV-1364
PV-1366-K	PV-1364

PV-M1367AD	PV-M1327	PV-4002	PV-2015S
PV-1442	PV-1340	PV-4003	PV-2003
PV-1442-K	PV-1340	PV-4005	PV-2015S
PV-1460	PV-1364	PV-4009	PV-2015S
PV-1462	PV-1364	PV-4010	PV-2004
PV-1540	PV-1340	PV-4016	PV-2015S
PV-1545	PV-1340	PV-4020	PV-2004
PV-1545-K	PV-1340	PV-4024	PV-2004
PV-1560	PV-1360	PV-4025S	PV-2015S
PV-1560-K	PV-1360	PV-4061	PV-4060
PV-1562	PV-1364	PV-4062K	PV-4060
PV-1564	PV-1364	PV-4063	PV-4060
PV-1740	PV-1640	PV-4064-K	PV-4060
PV-1740-K	PV-1640	PV-4065S	PV-4060
VV-2006	PV-M1326	PV-4066	PV-4060
PV-2008	PV-2004	PV-4068	PV-4060
PV-2012	PV-2004	PV-4069	PV-4060
VV-2016W	PV-M1326	PV-4101	PV-2101
PV-M2024	PV-M1324	PV-4110	PV-2110
PV-M2025	PV-M1325	PV-4127	PV-4120
PV-M2035	PV-M1325	PV-4151	PV-4120
PV-M2036	PV-M1326	PV-4160	PV-4120
PV-M2037	PV-M1327	PV-4164	PV-4120
PV-M2044	PV-M1324	PV-4201	PV-2201
PV-M2045	PV-M1325	PV-4208	PV-4210
PV-M2046	PV-M1326	PV-4214	PV-4210
PV-M2047	PV-M1327	PV-4250	PV-2201
PV-2308	PV-2301	PV-4251	PV-4260
PV-2408	PV-2409	PV-4264	PV-4262
PV-2509	PV-2501	PV-4265S	PV-4260
PV-2601	PV-4601	PV-S4266	PV-4262
PV-2601-K	PV-4601	PV-4268	PV-4260
VV-2706	PV-M1326	PV-S4270	PV-4262
PV-2801	PV-2800	PV-S4280	PV-4262
PV-2802	PV-2800	PV-4301	PV-2301
PV-2803	PV-2800	PV-4303	PV-2301
PV-2812	PV-2800	PV-4311	PV-4308
PV-2822	PV-2820	PV-4314-K	PV-4314
PV-2901	PV-2903	PV-4315S	PV-4308
PV-2904	PV-2900	PV-4325S	PV-4308
PV-2912	PV-2903	PV-4351	PV-4308
PV-3700	PV-2700	PV-4351-K	PV-4308
PV-3720	PV-2700	PV-4355S	PV-4308
PV-3900	PV-4900	PV-4358	PV-4308
PV-4002	PV-2004	PV-4361	PV-4314

PV-S4366	PV-4362	PV-4652	PV-4601
PV-S4380	PV-4362	PV-4652-K	PV-4603
PV-4401	PV-2401	PV-4653	PV-4603
PV-4402	PV-2401	PV-4657	PV-4603
PV-4408	PV-2409	PV-4658	PV-4601
PV-4409	PV-2409	PV-4659	PV-4603
PV-4410	PV-2409	PV-4660	PV-4603
PV-4411	PV-2409	PV-4661	PV-4601
PV-4414	PV-2409	PV-4662	PV-4601
PV-4415	PV-2409	PV-4663-K	PV-4603
PV-4425	PV-2409	PV-4664	PV-4603
PV-4451	PV-2401	PV-4666	PV-4603
PV-4456	PV-2409	PV-4669	PV-4603
PV-4458	PV-2409	PV-S4670	PV-4603
PV-4459	PV-2409	PV-S4670-K	PV-4603
PV-4460	PV-2409	PV-S4690	PV-S4680
PV-4461	PV-2409	PV-4720	PV-4700
PV-4462	PV-2409	PV-4720-K	PV-4700
PV-4465	PV-2409	PV-4780	PV-4768
PV-4469	PV-2409	PV-4800	PV-2800
PV-S4480	PV-4466	PV-4822	PV-4820
PV-4501	PV-2501	PV-4850	PV-2850
PV-4504	PV-2501	PV-4852	PV-4820
PV-4508	PV-4503	PV-4860	PV-4820
PV-4509	PV-2501	PV-4862	PV-4820
PV-4511	PV-4503	PV-4870	PV-4820
PV-4514	PV-4503	PV-4904	PV-4900
PV-4551	PV-2501	PV-4920	PV-4900
PV-4553	PV-4503	PV-4924	PV-4900
PV-4558	PV-4503	PV-4941-K	PV-4926
PV-4559	PV-2501	PV-4942-K	PV-4926
PV-4560	PV-4503	PV-4950	PV-4926
PV-4561	PV-4503	PV-4960-K	PV-4926
PV-4562	PV-4503	PV-4961	PV-4926
PV-4564	PV-4503	PV-4962	PV-4926
PV-S4566	PV-4503	PV-4970	PV-S4986
PV-4569	PV-4503	PV-7200	PV-7400
PV-4580	PV-4466	PV-7401	PV-7400
PV-S4580	PV-4466	PV-7450	PV-7400
PV-4608	PV-4601	PV-7451	PV-7400
PV-4609	PV-4603	PV-7452	PV-7400
PV-4611	PV-4601	PV-7457-K	PV-7661
PV-4614	PV-4603	PV-7662	PV-7661
PV-4617	PV-4601	PV-7664	PV-7661
PV-4651	PV-4601	PV-S7680	PV-S4680

VHQ620	PV-4603
VHQ620-K	PV-4603
VHQ640	PV-4603
VHQ640-K	PV-4603
VHQ650	PV-4603
VHQ660	PV-4603
VHQ660-K	PV-4603
VHQ720	PV-7400
VHQ740	PV-7400
VHQ750	PV-7400
VHQ760	PV-7400
VV-1306	PV-M1326
VV-1307	PV-M1327
VV-1316	PV-M1326
VV-1317W	PV-M1327
VV-2007	PV-M1327
VV-2017W	PV-M1327

VG2035	VR324
VG4001	VG2003
VG4005	VR500
VG4009	VR511
VG4010	VG2009
VG4011	VR512A
VG4012	VR334
VG4013	VG2009
VG4014	VR319
VG4016	VR505
VG4018	VR535
VG4019	VR319
VG4020	VG2019
VG4021	VG2019
VG4025	VR321
VG4029	VR321
VG4030	VG2030
VG4030A	VR327A
VG4031	VG2030
VG4032	VG2030
VG4033	VG2030
VG4035	VR324
VG4036	VR324
VG4038	VR332
VG4039	VR528
VG4053	VG2053
VG4055	VR338
VG4210	VR658HF
VG4215	VR658HF
VG4216	VR660HF
VG4217	VR657HF
VG4218	VR665HF
VG4230	VG2030
VG4230A	VR603AHF
VG4232	VG2030
VG4233	VG2030
VG4235	VR610HF
VG4239	VR673HF
VG4253	VR603AHF
VG4255	VR617HF
VG7500	VR250
VG7515	VR280
VG7575	VR285
VG7615	VR290
VG7675	VR295

Above updated 07/08/97

RCA VCR MANUAL X-REF

Model #	Use Manual
13TV40	T13005BK
13TVR45	T13017
19TVR01	13TVR03
PSVR81	PSVR61
T20005BK	T13005BK
T13018	T13015
T20015	T13015
T20018	T13015
T20020	T13015
VG2001	VR300
VG2007	VR330
VG2010	VR301
VG2013	VG2011A
VG2014	VR334
VG2016	VR335
VG2020	VG2019
VG2021	VR319
VG2030A	VR327A
VG2032	VR327A

VG7910	VG7610
VG7920	VG7620
VG7925	VG7620
VG7975	VG7685
VG7980	VG7685
VG7985	VG7685
VR273	VR270
VR273A	VR270
VR275	VR270
VR320	VR319
VR329	VR324
VR341	VR340
VR343	VR340
VR451	VR450
VR452	VR450
VR475	VR470
VR480	VR620HF
VR495	VR490
VR501A	VR327
VR502	VR501
VR503	VR327
VR503A	VR327A
VR504	VR324
VR506	VR319
VR506A	VR321
VR507	VR324
VR510	VR319
VR510A	VR321
VR512	VR334
VR513	VR327A
VR514	VR338
VR515	VR505
VR517	VR338
VR521	VR520
VR523	VR520
VR526	VR319
VR526A	VR321
VR535M	VR535
VR537	VR321
VR539	VR538
VR541	VR532
VR542	VR532
VR603HF	VR327
VR604HF	VR610HF
VR613HF	VR603AHF

VR625HF	VR620HF
VR664HF	VR658HF
VR672HF	VR610HF
VR678HF	VR676HF
VR680HF	VR665HF
VR684HF	VR674HF
VR725HF	VR721HF

Above revised 07-19-97

SANYO/FISHER VCR MANUAL X-REF

Model #	Use Manual
FVH-Z1	
FVH-T607	
FVH-S650	
FVH-T657	
FVH805	
FVH820	
FVH906	
FVH907	FVH906
FVH919	
FVH950	
FVH960	
FVH2502	
FVH2504	
FVH2507	
FVH2507U	FVH2507
FVH2509	
FVH2510	VHR5215
FVH2512	VHR5218
FVH2514	VHR5218
FVH4000	
FVH4050	
FVH4100	FVH4000
FVH4200	
FVH4502	
FVH4504	
FVH4505	FVH4504
FVH4508	

FVH4508S	FVH4508	TVR1944	
FVH4509	FVH4508	VCR4400	
FVH4511	FVH4512	VCR4400-II	VCR4400
FVH4512		VCR6400	
FVH4513	VHR5428	VHR-M447	
FVH4514	VHR5432	VHR500	
FVH4515	VHR5432	VHR-H607	FVH-T607
FVH4516	VHR5432	VHR-H647	
FVH4516A	VWM350	VHR-H657	
FVH4520	FVH4512	VHR2550	
FVH4900		VHR2700	
FVH4902		VHR2900	
FVH4903	FVH4902	VHR3250	
FVH4907		VHR3350	
FVH4909		VHR3700	
FVH4909S	VHR9413A	VHR3950	
FVH4910		VHR5203	VWM210
FVH4911	VHR9421	VHR5211	VWM220
FVH4912		VHR5212	VWM220
FVH4913		VHR5214	FVH2509
FVH4913A	VWM650	VHR5215	
FVH4914	VHR9430	VHR5216	FVH2509
FVH4920	VHR9421	VHR5218	
FVH4923	VWM650	VHR5403	VWM310
FVH4927	VWM650	VHR5408U	
FVH4950		VHR5416	VWM320
FVH5400		VHR5417	VWM320
FVH5550		VHR5418	
FVH-D5600		VHR5420	VHR5423
FVH6200		VHR5422	VHR5423
FVH6300		VHR5423	
FVH6500		VHR5428	
FVH6600		VHR5431	
FVH-S6800		VHR5432	
FVH7200		VHR5436	VHR5432
FVH7300		VHR5441	VWM350
FVH7315	FVH7300	VHR8100	
FVH7400		VHR8120	
FVH7600		VHR8310	
FVH7615	FVH7600	VHR8700	
FVH8200		VHR9100	
FVH8300		VHR9200	VHR9100
FVH8700		VHR9270	
FVH8901		VHR9280	
FVH8902		VHR9280M	VHR9280

VHR9300
VHR9370
VHR9385
VHR9385M VHR9385
VHR9413A
VHR9415
VHR9421
VHR9428 VHR9430
VHR9430
VHR9433 VWM650
VHR9435 VWM650
VHR9440
VHR9500
VHR9600
VHR9670
VWM210
VWM220
VWM230
VWM240
VWM260
VWM310
VWM320
VWM330 VHR5423
VWM340 VHR5432
VWM350
VWM352
VWM510
VWM620
VWM620A
VWM638A
VWM640 VHR9430
VWM650

Above edited 07-08-97