

KENT - Mark D.

MICRO SERIES Amplifiers Piggy Back / TEMP SW. MODS 3-1-93

✓ 1) USE THERMAL GREASE UNDER ALL PEP1
Switch locations IN MICRO SERIES AMPLIFIERS.

✓ MICRO TUBE 200 3 LOCATIONS
✓ MICRO TUBE 100 1 LOCATION
✓ MICRO FET 100 1 LOCATION

○ 2) PIGGY BACK BOARD MOD FOR n tube 100
USE PLIERS TO HOLD WIRE AT BOARD END
WHEN BENDING WIRE TO AVOID LIFTING PCB MOUNT
TRACES

○ 3) EXAMINE PIGGY BACK BOARDS FOR SOLDER
BRIDGES. I FOUND ONE ON THE BOARD I
USED FOR TESTING

R