


USE RTV BETWEEN CAP AND PCB

CABLE TIES AT
C301, C302. TIE POINTS
BELOW TOP OF CAPACITOR




T0-220'S (5PLCS)

0.07

T0-220 LEAD FORMING

INSERT LEADS OF
T0-92'S (X2) INTO
PCB 0.07" BEFORE
SOLDERING.



USE RTV
BETWEEN CAP AND PCB

REVISION HISTORY

ZONE	REV.	DESCRIPTION	SIGNATURE	DATE
	A	ADD GND WIRE, CMPLTE TO REL.		3/9/92
	B	CORRECT FOR DETAIL DWG, B756		3/16/92
	C	ADD TUBE SKT ASSY		3/23/92

RED UL1007,
10"

PEPI SWITCH,
287022

BLACK UL1007,
10"

TUBE SOCKET ASSEMBLY

10 1/4" CABLE

12 1/2" CABLE

581305 (x2)

585050

582121

581080

ADA SIGNAL PROCESSORS, INC.
7303-D EDGEWATER DR., OAKLAND, CA 94621

TITLE MICROTUBE 100, PCB WIRING
DETAIL (780053)

DRAWN: D. WIRT SIZE B DRAWING NO. 745 REV C

ENGR: © COPYRIGHT 1992 SCALE: DATE: 3/4/92 SHEET 1 OF 1



http://www.adadepot.com