

Model: KP-53HS10, KP-61HS10**No.** 501R1**Subject:** "D" & "DS" Board Part Number Differences
Based on Serial Number Ranges**Date:** September 29, 2000**Symptom:****(XXXX)**

Depending on the television serial number the "D" Board will have a different part number.

Solution:

Please refer to the tables below if any of the below boards need replacing

KP-53HS10

Description	All Serial Number Starting With 90	All Serial Number Starting With 97.
"D" & "DS" Boards together	A-1346-873-A	A-1346-993-A
"D" Board (Only)	A-1343-771-A	A-1343-959-A
"DS" Board (only)	A-1343-712-A	A-1343-712-A

KP-61HS10

Description	All Serial Number Starting With 90
"D" & "DS" Boards together	A-1346-899-A
"D" Board (only)	A-1343-772-A
"DS" Board (only)	A-1343-712-A

Note: There are no P/N changes between Serial Number ranges on the KP-61HS10