
Model: CPD-15SF2, CPD-17SF2, CPD-100VS, CPD-100SF, CPD-200SF, CPD-20SF2, CPD-300SF, CPD-120VS, CPD-220VS, GDM-17SE2T, GDM-20SE2T, GDM-W900**No. 214****Subject: Procedure for Built-In Raster Aging & Color Bar Patterns****Date:** August 24, 1998**Symptom:
(1181)**

The unit has come in for service. Raster Aging is necessary for warming the unit prior to adjusting set up. The Color Bars Pattern is useful for testing symptoms. The Built-In Raster Aging and Color Bars pattern modes should be used for these purposes. Special procedures are required to enable the Built-In Raster Aging and Color Bars pattern functions.

Solution:

Please refer to the following procedures to put the unit into the Built-In Raster Aging and Color Bars pattern modes. Use the procedures listed for the particular model. The times listed are approximate.

BUILT-IN RASTER AGING**CPD-15SF2, CPD-17SF2, CPD-100VS, CPD-100SF, CPD-200SF:**

1. Connect AC cable.
2. Remove Video Cable.
3. Turn On Power Button and hold the Power Button in for 2 seconds.

CPD-120VS, CPD-220VS:

1. Connect AC cable.
2. Remove Video Cable.
3. Turn On Power Button and hold the Power Button in for 4 seconds.

CPD-20SF2, CPD-300SF, GDM-17SE2T, GDM-20SE2T, GDM-W900:

1. Connect AC cable and turn On Power Button.
2. Remove Video Cable. Wait for Power Save.
3. Hold the " Option " Button in for 2 seconds.

BUILT-IN COLOR BARS PATTERN**CPD-15SF2, CPD-17SF2, CPD-100VS, CPD-100SF, CPD-200SF:**

1. Connect AC cable.
2. Remove Video Cable.
3. Turn On Power Button and hold the Power Button in for 5 seconds.

CONT.

CPD-120VS, CPD-220VS:

1. Connect AC cable.
2. Remove Video Cable.
3. Turn On Power Button and hold the Power Button in for 8 seconds.

CPD-20SF2, CPD-300SF, GDM-17SE2T, GDM-20SE2T, GDM-W900:

1. Connect AC cable and turn On Power Button.
2. Remove Video Cable. Wait for Power Save.
3. Hold the " Contrast + " Button in for 2 seconds.

The set up procedure is completed.